



# Prioritized Technology: Planetary Protection Expanded Bioburden Reduction Technique Toolbox

## Technical Goal

To enable planetary protection (PP) capabilities to meet the  $10^{-4}$  inadvertent contamination probability for forward planetary protection through expansion of bioburden reduction technique toolbox and materials compatibility:

**Near Term: Compatibility and Specifications Expansion** – materials compatibility, increased size scale and expanded specifications for **Heat Microbial Reduction** – expanded specs: mated surfaces, embedded organisms ; **Vapor Hydrogen Peroxide** – validate VHP model, dose dependences of dose (e.g. pressure, time, temp, geometry)

**Mid Term: - Development of Alternative Approaches: Gamma Radiation** –develop specs for in-flight and pre-launch dose condition; **DoD Techniques** – Leverage & tailor existing approaches for spacecraft applications

**Long-Term: Scaling and Risk Mitigation: Interrupted microbial reduction processing** experimentation (e.g. Does 110C at 20h + 110C at 30h = 110C at 50h?);

**Summed bioburden reduction approaches** e.g. VHP+HMR, HMR+VHP

## Technical Status

### Current NASA Methods for Bioburden Reduction:

**A. Heat Microbial Reduction:** Understood for free surfaces <200C; T >200C not well-characterized for free & mated surfaces and embedded; Hidden compatibilities may exist --MIL-SPEC 810F (High Temperature Compliant) and Automotive (AEC series) parts.

**B. Vapor Hydrogen Peroxide:** parts-level VHP has well-defined V&V, process dependencies not understood as they still require evaluation and bio-indicator verification. Hidden compatibilities & size scalability exist in data from other agencies.

Limited experimental work exists for other techniques (gamma/plasma/e-beam/laser; other Agencies standards for NASA use, interrupted processing, combined credit, cleaning for specific populations).

**Forward Contamination Detection:** Sample collection and processing efficiencies cover large areas (wipes >1m<sup>2</sup>), quantitative metagenomics requires higher resolution (swabs <25 cm<sup>2</sup>); Limited experimental work on microbial lethality for space conditions

## Mission Applications

### What is enabled if we achieve the goal?

#### Forward Contamination Risk Reduction for:

- Europa: Clipper, Lander, Sample Return
- Enceladus: Plume Sample Return, Lander Sample Return
- Ceres, Vesta, Mars, Titan: Landers, Rovers/Boats, Sample Return

**Risk mitigation for activities common to the project lifecycle:** Current mitigations are conservative implementations, given limited technology development (for example, rework recontamination after integration has not been explored experimentally from a planetary protection POV)

**Synergistic impacts :** **At NASA**—human exploration; **Outside NASA**--Department of Defense and National Institutes of Health applications for use with biohazard/bioweapon decontamination activities.

## Development Cost and Schedule