



# Prioritized Technology: Technologies to Extract and Process Materials on Ocean Worlds for Life Detection

## Technical Goals


- Extract potential monomeric or polymeric biomarkers at **< 1 ppb/wt** from ice, liquid (**< 5 mL**), or aerosol (**> 10<sup>6</sup>** submicron particles) without organic solvent.
- Process liquid or ice to separate or distinguish salts and minerals from biomarkers.
- Concentrate biomarkers to **pmol/mL** from **10's of mL** of ice or liquid.
- Amplify polymers with non-random repeating patterns.

## Technical Status/ SOA

- SAM/ MSL – volume of solid material handled is 50  $\mu\text{L}$  – extraction is by heat and derivatization chemistry.
- PHOENIX- Tega instrument – extraction by heat- handles  $\sim 40 \mu\text{L}$
- PICASSO MACROS- solvent and heat extraction system for drill samples/LC  $\rightarrow$  LDMS
- Urey instrument (descoped from EXOMARS )-subcritical  $\text{H}_2\text{O}$  extraction (SCWE)
- Supercritical  $\text{CO}_2$  extraction (not yet adapted for space use)
- MSL/SAM hydrocarbon trap – 1 pmol/150 mg/soil (dry chemistry) – concentrates hydrocarbons by a factor  $\sim 1000$
- MIDP-funded Precision Subsampling System – target layers of interest in core sample – 1 mm layer from 10 cm core
- PICASSO MILA Chemical Laptop microfluidic handling system – for example the fluorescent tagging capability
- PICASSO - Open tube ion/LC – ( with focus on the sample prep portion of this instrument and not the analysis)

## Mission Applications

- Release of biomarkers from natural their matrices will facilitate their identification.
- Determining extraction efficiencies under native conditions will enable determination of abundance of biomarkers in matrix.
- Quantitative isolation, concentration, and amplification expands the capability to detect biomarkers.



*This image shows soil on the doors of the Thermal and Evolved Gas Analyzer (TEGA) onboard NASA's Phoenix Mars Lander.*